

# **HEPA & ULPA**

FILTER HANDLING INSTRUCTIONS



# **INSTRUCTIONS FOR:**

- Absolute® VG, XS, & XH
- Filtra 2000
- Megalam

# STORAGE INSTRUCTIONS

- Store filter in vertical position in original box.
- Keep in temperatures between 5°C 40°C.
- Store in a clean, dry and frost-protected place
- Do not keep filter in direct sunlight.
- Maximum recommended shelf life, before installation, is seven years provided the filter is kept under optimal storage conditions.

#### HANDLING INSTRUCTIONS

**Caution**: Handle filter with care. Do not touch the filter media. The slightest touch may lead to leakage. Do not drop filter to prevent severe damage. Avoid liquid spills/splashes on filter.

- Transport and carry vertically.
- Unpacking filters: lift filter by the frame, be careful not to damage the gasket or media. When available, follow instructions on the box!
- Avoid twisting filter frame.
- Large panel filters require two people when handling.

#### **INSTALLATION INSTRUCTIONS**

- Keep filter in box as long as possible before installation to avoid damage.
- For vertical installations, make sure filter is fitted with standing pleats.
- Make sure the gasket is not damaged during installation.

#### **FILTER CHANGE**

- Camfil recommends protective equipment such as overalls, gloves and face masks when changing filters.
- Always check local regulations before changing filters
- Filters are not reusable. Used filters should be disposed of according to local regulations.



# DO NOT

use a blade to open box



## DO NOT

apply load on filter media



# DO NOT

touch filter media or push on the grids



## **ONLY HANDLE**

large filters by two persons, carry filters vertically



#### **ONLY LIFT**

panel filters at the corners of the frame