

EPA, HEPA, ULPA

HANDLING AND MAINTENANCE INSTRUCTION



INSTRUCTIONS FOR:

- Absolute[™]
- Closepleat
- Megalam®

STORAGE INSTRUCTIONS

- Store filter in vertical position in original box
- Keep in temperatures between 5°C 40°C
- Store in a clean, dry and frost-protected place
- Do not keep filter in direct sunlight
- Maximum recommended shelf time, before installation, is 7 years provided that filter is kept under optimal storage conditions

HANDLING INSTRUCTIONS

Caution: Handle filter with care. Do not touch the filter media as the slightest touch may lead to leakage. Do not drop filter as it may get severly damaged. Avoid spills or splashes of liquids on filter.

- Transport and carry vertically
- When unpacking filters: lift filter by the frame, be careful not to damage the gasket or media. When available, follow instructions on box!

INSTALLATION INSTRUCTIONS

- Keep filter in box as long as possible before installation to avoid damage
- For vertical installations make sure filter is fitted with standing pleats
- Make sure the gasket is not damaged during installation

FILTER CHANGE

- Camfil recommends protective equipment like overalls, gloves and face masks when changing filters
- Always check local regulations before changing filters
- Filters are not reusable, used filters should be disposed of according to local regulations



DO NOT

use a blade to open box



DO NOT

apply load on filter media



DO NOT

touch filter media or push on the grids



ONLY HANDLE

large filters by two persons, carry filters vertically



ONLY LIFT

panel filters at the corners of the frame