# Filter holding frames

HANDLING AND MAINTENANCE INSTRUCTION



# **INSTRUCTIONS FOR:**

- FastFrame
- Universal Filter Holding Frame

#### **STORAGE**

- Store in a dry and clean place
- Store in original box

## HANDLING INSTRUCTIONS

Handle with care to avoid damages to the frame

## **INSTALLATION**

- Please take note of the airflow and air filter requirements of the application before installing a filter holding frame, e.g. Fast-Frame is suitable for installations with dust side filter change
- Add a gasket if needed to avoid leakage
- Filter holding frames can be installed in larger filter banks using the Filter bank assembly system (RZA,MZA,ZWB), refer product documentation for more information

### **MAINTENANCE**

- Camfil recommends protective equipment like overalls, gloves and face masks when performing maintenance work and filter changes
- When needed clean frame with water and a mild detergent
- Check gasket for damages, replace when necessary to avoid leakage
- Spare clamps available for replacement
- Filter holding frames that have reached end-of-life are disposed of in accordance with local regulations